




SG-1 INSTRUCTION CARD


STEP 1

HOLD FRAME AS PICTURED. GRAB EACH LENS IN UPPER CORNER NEAREST TO NOSE BRIDGE AND PUSH LENS DOWNWARD WHILE LIFTING CENTER OF FRAME IN UPWARD DIRECTION.




STEP 2

ONCE YOU'VE CREATED GAP PUSH INWARDS, AND DOWN AT THE SAME TIME. USING YOUR THUMB AND INDEX FINGER.




STEP 3

LENS WILL RELEASE FROM TABS ON INSIDE OF FRAME.




www.wileyx.com 1.800.776.7842



TEMPLE REMOVAL / REPLACEMENT


Step 1

Hold Frame as Pictured.




Step 2

Using thumb nail, push release notch and pull temple outwards



Step 3

Replace temple with strap.



www.wileyx.com 1.800.776.7842